



EESM5060 Embedded Systems

LAB #5

Applications with Bluetooth Low Energy Glance Sport Kit

ECE-EESM5060-LAB5
By Prof. Chi Ying Tsui

Version 1.0
SEPT 4, 2023

Electronic & Computer Engineering
The Hong Kong University of Science and Technology
Clear Water Bay, Kowloon, Hong Kong

OBJECTIVE

The objective of this lab is to develop application using commercial sports product, Glance. Glance is a BLE wearable used for motion analysis and movement feature extraction. The CWB Sports Kit series is a combination of hardware and apps library, developed based on our motion analysis and feature extraction core. The small sensor device collects motion data which can be further interpret into useful information for sports, health and rehabilitation studies. For the golf application, similar device can be used to capture swing data, reconstructs the path. Partners can then use this information to review club head speed, consistency, face angle in different reply speed and viewing angle.

Getting XYZ gravity values from our phone and it can interpret as walking steps. With BLE connectivity and by constructing bonding pairs, temperature profile can be used to send temperature values to our phone. In this lab, we use glance wearable sports kit which provide a comprehensive libraries and APIs which allow more precise algorithm and application development.

This sports kit software contains a list of pre-built commands:

```
SET_USER_DATA_PROFILE; GET_USER_DATA_PROFILE  
SET_USER_DATA_GOAL; GET_ DATA_GOAL  
GET_FW_VERSION  
SET_DATETIME;GET_DATETIME  
SET_AUTOWALK_INTERVAL;GET_AUTOWALK_INTERVAL  
GET_STEP_COUNT
```

It also allow real-time sampling of streaming of RSC and Motion Stream data. In this lab, the glance sensor will collect motion information, with BLE to talk with phone Apps.



Glance Wearable

Understanding the system architecture:
Inside onCreate()

```

@Override
protected void onCreate(Bundle savedInstanceState) {
    super.onCreate(savedInstanceState);
    setContentView(R.layout.activity_glance_main);

    Log.d(TAG, "onCreate()");

    mIsScanStarted = false;

    // Exit if BLE is not supported on the system
    if (isBLESupported() == false) {
        Toast.makeText(this, R.string.ble_not_supported, Toast.LENGTH_SHORT).show();
        finish();
    }

    // Exit if cannot get BluetoothAdapter
    mBluetoothAdapter = getBluetoothAdapter();
    if (mBluetoothAdapter == null) {
        Log.e(TAG, "Cannot get Bluetooth Adapter");
        Toast.makeText(this, R.string.ble_not_supported, Toast.LENGTH_SHORT).show();
        finish();
    }

    mIsFoundDevice = false;
    mIsConnected = false;
    mIsStartRSC = false;
    mIsStartMotionStream = false;
    mIsUpSideDown = true;
    mIsTimeFormat24h = true;

    mService = null;

    mLatestBLEDeviceAddress = null;
    mConnectedDeviceAddress = null;

    // mGetBatteryHandler = new Handler();


    initUI();
    service_init();
} // end onCreate
    
```

Check BLE availability

UI part

Functional part

initGraphFragment()



```

private void InitUI() {
    mLatestBLEDeviceAddressTextView = (TextView) findViewById(R.id.latestDeviceAddress);
    mLatestBLEDeviceAddressTextView.setText("");
    mLatestBLEDeviceRSSITextView = (TextView) findViewById(R.id.rssiText);
    mLatestBLEDeviceRSSITextView.setText("");
    mGlanceDeviceAddressSpinnerList = (Spinner) findViewById(R.id.glanceDeviceAddressList);
    mConnectStateTextView = (TextView) findViewById(R.id.textConnectState);
    mConnectStateTextView.setText("");
    mConnectButton = (Button) findViewById(R.id.butConnect);
    mConnectButton.setOnClickListener(mConnectionButtonListener);
    mConnectButton.setEnabled(false);
    mConnectButton.setText(getResources().getString(R.string.connect_string));
    mScanButton = (Button) findViewById(R.id.butScan);
    mScanButton.setOnClickListener(mScanListener);
    mReadRSCButton = (Button) findViewById(R.id.butGetRSC);
    mReadRSCButton.setText(getResources().getString(R.string.read_rsc));
    mReadRSCButton.setEnabled(false);
    mReadRSCButton.setOnClickListener(mRSCButtonListener);
    mReadMotionStreamButton = (Button) findViewById(R.id.butGetMotionStream);
    // mReadMotionStreamButton.setText(getResources().getString(R.string.str_start_motion_stream));
    mReadMotionStreamButton.setEnabled(false);
    mReadMotionStreamButton.setOnClickListener(mMotionStreamListener);
    mGetBatteryButton = (Button) findViewById(R.id.butGetBatteryLvl);
    mGetBatteryButton.setOnClickListener(mBatteryButtonListener);
    mGetBatteryButton.setEnabled(false);
    mRSCResultTextView = (TextView) findViewById(R.id.textRSC);
    mRSCResultTextView.setText("");
    mBatteryLevelTextView = (TextView) findViewById(R.id.textBatteryLevel);
    mBatteryLevelTextView.setText("");
    mUARTResultTextView = (TextView) findViewById(R.id.textUART);
    mUARTResultTextView.setMovementMethod(new ScrollingMovementMethod());
    mUARTResultTextView.setText("");
    mPrevButton = (Button) findViewById(R.id.butPrev);
    mPrevButton.setOnClickListener(mPrevButtonListener);
    mPrevButton.setEnabled(true);
    mNextButton = (Button) findViewById(R.id.butNext);
    mNextButton.setOnClickListener(mNextButtonListener);
    mNextButton.setEnabled(true);
    mGetSetButton = (Button) findViewById(R.id.butGetSet);
    mGetSetButton.setEnabled(false);
    mGetSetButton.setOnClickListener(getOnClickListenerByIndex(mCurrentCmdIndex));
    mButtonLabelTextView = (TextView) findViewById(R.id.textCommandButton);
    mButtonLabelTextView.setText(getButtonString(mCurrentCmdIndex));
    // mScannedGlanceDeviceArrayList.addAll(mScannedGlanceDeviceList);
    mScannedGlanceDeviceListAdapter = new ArrayAdapter<String>(this,
        android.R.layout.simple_spinner_item, mScannedGlanceDeviceArrayList);
    mGlanceDeviceAddressSpinnerList.setAdapter(mScannedGlanceDeviceListAdapter);
} // end InitUI

InitUI()

private void service_init() {
    Log.d(TAG, "service init");
    Intent bindIntent = new Intent(this, GlanceProtocolService.class);
    bindService(bindIntent, mServiceConnection, Context.BIND_AUTO_CREATE);


    LocalBroadcastManager.getInstance(this).registerReceiver(mBluetoothServiceBroadcastReceiver, makeGattUpdateIntentFilter());
}

service_init()

```


“Service init” will start bluetooth service connection, setup bluetooth service receiver for handling service event. Intent filter are added to tell what kind of services are needed in protocol


Program procedure (To plan what should need to do to reach the target)	
Task 1 – Familiar with the project environment, build the app and connect to glance	
Task 2 – Getting data from glance, understand how it work	
Task 3 – Get gravity value from sensor and plot a real-time stream graph	
Start to do:	
Task 1	Familiar with the project, build and try the app
External resources	
	1) Phone of Android 8.0 or above and support BLE is recommended. You can set target build to 8.0 to run in other android phone
Procedure of the task:	
<p>01) Open Android Studio in the startup menu Start -> Android Studio->Android Studio</p> <div data-bbox="924 1057 1428 1205" data-label="Image"> </div> <p>02) The Glance Sample Project was put under folder \lab5</p> <p>In the “Welcome to Android Studio” Interface, choose “Open an existing Android Studio Project” option.</p> <p>Select “build.gradle” in the path lab5\BLEFrameworkAS_rev6638\android\build.gradle</p>	




then click OK

- 03) Make sure the module is configured as below. Check the build dependencies is configured correctly. Compile Sdk Version(33), Build Tools Version(33.0.x)






- 04) Click Build->Make Project, Build->Build Bundle(s)/APK(s)->Build APK(s) to build the App
 05) Install the App in android phone and try.



- 06) Make sure you can open the App like this **Self-Checkpoint 1**



07) Press ONCE to power on the glance device,


Find the Mac address(in the label behind) and connect to the App

- 1) Open the App->Scan->Find out and click the Mac address(last 4 digits) in the list-> Click Connect
- 2) The status should be "Connecting", press the glance device once
- 3) If success, the status should change to "Connected"
- 4) If fail, kill the App and repeat 1)-3) again

Task 2 | Getting data from glance and understand how it work

A firmware was already loaded inside the glance device. By pressing it(Just press, do not hold), it toggle in different modes with UI shown in OLED.

UI flow:



with this expression methodology, many other modes can be added in this chain.

Once power up, the device will start recording steps, calories and sleep parameters immediately.

Play with the app, click “Read RSC” button and see how the parameters changes:

```
Walking Calories: 103.0 kcal
Walking Total Distance: 2020.0 m
Walking Steps: 2706.0
Walking Duration: 32.0mins
Running Calories: 8.0 kcal
Running Total Distance: 80.0 m
Running Steps: 92.0
Running Duration: 1.0mins
Total Calories: 1014.0 kcal
Activity: WALKING
```

Exercise1: (This part is just for reference, it is NOT an requirement for this lab)

- 1) Spend some time and see how the above parameters changes
- 2) Parameters are live update.
- 3) Locate the code in the project associating with this feature. Modify the code to disable this feature.

Exercise2: (This part is just for reference, it is NOT an requirement for this lab AND AutoWalk mode was removed in firmware)

Try to send command to the device:

Try the “ Get AutoWalk and Set AutoWalk” command. After that, “Start RSC” to see how parameter change. Can you tell what is AutoWalk mode?



While the device is **SET TO AutoWalk mode**, install another App Glance
Source:

From apkpure (<https://apkpure.com/glance-wearable-for-runner/com.cwb.glance>)

OR “Glance_1.16-2.apk” in zip file


After installation and pairing with the device, you should be able to get something like this.
The app provide another mean to interpret the data(Make sure you have to disconnect from previous App before connecting to this App)



To pair the device:

Click Glance, Press the device, If connected, your device will vibrate once.

Can you see the step count is still incrementing as we set the device in AutoWalk Mode before




There are 3 operation modes in Dashboard: Activity-Sleep-ProRun. You can further investigate how it works.

(SetAutoWalk function may not work and this is okay as some of glance devices firmware had been upgraded.)

SetAutoWalk back to 0 after this step

SetAutoWalk back to 0 after this step

SetAutoWalk back to 0 after this step

Knowledge Check Point:

What did you learnt up to now? This is a real work that engineers make a product!

Now go back to the **glanceSampleApp**

There are a number of commands in the command list. If we want to trim down the command list menu to the list as below, could you try how to accomplish this?

Target:

Set/Get AutoWalk<->Set Secondary Display(Ascii String)<->Set Secondary Display(Bitmap)<->Get Firmware Version

Hints: Go back into initUI and check with
getButtonString,setOnClickListenerByIndex,COMMAND_LIST

Task 3	Gyroscope and gravity sensor data graph plotting(This part is required)
---------------	--

Knowledge learn in this task:

- | | |
|--|---|
| | 1) Identify how to get gyroscope and gravity data from glance for further processing


2) Identify how to stream data from glance in fast sampling interval

3) Identify how to use plot API |
|--|---|


Code studying: Identify the mechanism how accelerometer graph plot were done. In task 3, show also the gyro data graph.

Requirments:

- 1) Change the text:



- 2) Put the 2 graphs in parallel, show also the gyro data, with Start/Stop Streaming button in below:



Hints: Edit including, GraphFragment.java and fragment_layout_graph.xml file
Reference how variable, mGraphViewAccl doing

For your information, if you want to develop an APP using Glance Protocol in future, you have to add the service in manifest.xml



Please notice you have to add:

```
<service android:enabled="true"
android:name="com.cwb.bleframework.GlanceProtocolService" />
```

when using the glance protocolservice

Test the apps if you can see two graphs appeared as above and is it reasonable. **Self-Checkpoint 2(This part is required)**

Before you leave, there are two graphs of X-,Y-,Z- values, that one of them describes “Walking” and the other one describes “Running”. Could you distinguish among them and reasons? Using what you learnt in the class?



Hand-in method:

In the class demonstration to Person-In-Charge